



32-0003-01

BILLET TOURING BACKREST

UNIVERSAL
(MUST BE INSTALLED w/ BRACKET KIT)

PARTS INCLUDED

- 1 - Billet Touring Backrest
- 4 - M10-1.5x20mm Button Head Bolt



TOOLS REQUIRED

- 6mm Allen Wrench

INSTALLATION INSTRUCTIONS

- 1) Mount the backrest bracket kit per the instructions included with the bracket kit.
- 2) Place the billet backrest uprights between the two backrest brackets and secure together using the four supplied M10-1.5x20mm button head bolts.
- 3) Fully tighten all mounting hardware on the backrest and mounting brackets.

NOTE: If installing both a backrest and cruiser rack (part #31-0001-01), the small rack mounting brackets must go between the mounting brackets and the backrest uprights. Refer to the cruiser rack instructions for more details.

WARNING

ENSURE ALL HARWARE IS SECURE AND FULLY TIGHTENED PRIOR TO RIDING YOUR MOTORCYCLE. FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY