



32-0004-01

STEEL SHORT BACKREST

UNIVERSAL  
(MUST BE INSTALLED w/ BRACKET KIT)

#### PARTS INCLUDED

- 1 - Steel Short Backrest
- 4 - M10-1.5x20mm Button Head Bolt



#### TOOLS REQUIRED

6mm Allen Wrench

#### INSTALLATION INSTRUCTIONS

- 1) Mount the backrest bracket kit per the instructions included with the bracket kit.
- 2) Place the billet backrest uprights between the two backrest brackets and secure together using the four supplied M10-1.5x20mm button head bolts.
- 3) Fully tighten all mounting hardware on the backrest and mounting brackets.

#### WARNING

ENSURE ALL HARWARE IS SECURE AND FULLY TIGHTENED PRIOR TO RIDING YOUR MOTORCYCLE. FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY