



56-1002-01

PASSENGER FLOORBOARDS

HONDA VT600C SHADOW VLX 1988-98
HONDA VF750C MAGNA 1994-03



PARTS INCLUDED

- 2 - Passenger Floorboards (Left & Right)
- 2 - M6-1.0x40mm Button Head Bolts
- 2 - M6-1.0 Hex Nylock Nuts
- 4 - 6mm Flat Washers
- 2 - Nylon Washers

TOOLS REQUIRED

- Ratchet
- 10mm Socket
- 10mm Wrench
- Needlenose Pliers

INSTALLATION INSTRUCTIONS

- 1) Locate and remove the factory cotter pins and mounting pins that secure the original passenger foot pegs to the mounts. Remove the original foot pegs.
- 2) Place the right side passenger floorboard mounting block inside the peg mount on the motorcycle frame. Using one supplied M6-1.0x40mm button head bolt, one M6-1.0 hex nylock nut, and two 6mm flat washers, secure the floorboard mount to the motorcycle. Do not fully tighten.

NOTE: If, when the mounting bolt is tightened, the floorboard mounting block is still loose inside the frame mount, you can use the supplied nylon washers to shim the mount in order to get a tight fit.

- 3) Lower the floorboard and check the level of it, if it is low or high, you can adjust the set screw on the back side of the floorboard mount to your preference.
- 4) Fully tighten the mounting bolt.
- 5) Repeat steps 1-4 for the left side.